

# #405 SHOWER CURTAIN ROD



## PARTS CHECKLIST

### QUANTITY

- 1 34" X 32 " CORNER ROD
- 1 40" STRAIGHT ROD WITH MALE END
- 2 8" THREADED INSERTS
- 2 3" CAST WALL BRACKETS
- 8 SCREWS

## INSTALLATION INSTRUCTIONS

ASSEMBLE CORNER ROD AND STRAIGHT ROD BY INSERTING MALE END OF STRAIGHT ROD INTO CORNER ROD.

MEASURE LENGTH AND WIDTH WHERE CURTAIN ROD WILL BE INSTALLED.

USE A TUBING CUTTER AND PROTECT FINISH WITH MASKING TAPE

TRIM CURTAIN ROD TO FIT MEASUREMENTS ALLOWING 11/16" FOR THICKNESS OF WALL BRACKET

DRILL WALL FOR SCREW HOLES IN BRACKETS, USE ANCHORS, IF NEEDED.

INSERT THREADED INSERTS INTO ROD, THREAD ON WALL BRACKETS

USING EITHER THE SCREWS PROVIDED, OR IF APPROPRIATE, OTHER SCREWS, ATTACH CURTAIN ROD BRACKETS TO WALL.

NOTE: IF YOU ARE INSTALLING A 404-1 CEILING SUPPORT ROD, SLIP RINGLET ONTO ROD BEFORE ATTACHING WALL BRACKETS.